



Compound 88 User Manual

Features

- 8 True Bypass Loops (electromechanical relay switching)
- 8 Programmable Channels with "All OFF" in each switch
- Programming each channel by using DIP switch
- 1 Non-Buffered input, & 1 Buffered Input (High Quality Clean Buffer Circuit)
- 1 output
- Red LED for Channel Status Indicator
- Blue LED for Loop Status Indicator
- Heavy Duty Footswitches, Gold Plated Relay and construction with High-Quality Components
- Light Weight Aluminum Enclosure , Dimensions 457x56x40 mm or 18.00x2.20x1.57 Inch
- 9VDC 400 mA Center Negative 2.1mm. (Ac Adaptor Not included)

Quick Start Guide

This compound 88 has 8 loops & 8 Programmable Channels. You just plug your chosen effect pedals into the Send and Return socket Loops.

Signal flows from input to loop1, loop2, loop3, loop4, loop5, loop6, loop7, loop8 and output.

When bypass all, the signal flows from Input to output.

* You can choose Buffer input or Non-Buffer Input

You can turn on or off in numbered switches in each of eight **DIP** Bank switches. Just determine which effect you want to use simultaneously in each Channel.

For Example

- Switch A could be programmed by using DIP switches to activate Loops 1,5
- Switch B could be programmed by using DIP switches to activate Loops 1,2,6,8
- Switch C could be programmed by using DIP switches to activate Loops 4,6
- Switch D could be programmed by using DIP switches to activate Loops 2,3,6
- Switch E could be programmed by using DIP switches to activate Loops 1,2,5,7,8
- Switch F could be programmed by using DIP switches to activate Loops 8
- Switch G could be programmed by using DIP switches to activate Loops 1
- Switch H could be programmed by using DIP switches to activate Loops 1,2,3,4,5,6,7,8

There is a BLUE LED for every effect loop in use for each Channel. This means that once you have programmed, tapping on Channel A will display blue light for all effect loops you have assigned to Channel A. The Status Indicator for channel in use is RED LED. You can go from one channel to another by tapping just once.

Master Bypass

"All OFF" in each switch If you want to take all pedals off, you just tap again on the footswitch of each channel in use. To go to a particular channel after that, you just tap on that particular channel footswitch again